

## ΒY **UTHERS**

\*\*SENERAL\_\*\*  $HDISTWAY_-$  THE HDISTWAY MUST BE IN ACCORDANCE WITH SAFETY CODE FOR ELEVATURS (ASME A17.1 OR 344-2000) AND ALL STATE/PROVINCIAL AND LOCAL CODES.

MINIMUM DYERHEAD CLEARANCE DEVIER/AGENT MUST ENSURE MINIMUM DVERHEAD CLEARANCE IS IN COMPLIANCE WITH CODES.

CONSTRUCTION SITE— DWNER/AGENT TO PROVIDE ALL MASDNRY, CARPENTRY AND DRYVALL WORK AS REQUIRED AND SHALL PATCH AN MAKE GOOD CINCLUDING FINISH PAINTING) ALL AREAS WHERE WALLS/FLICIRS MAY REQUIRE TO BE CUT, DRILLED OR ALTERED IN ANY WAY TO PERMIT THE PROPER INSTALLATION OF THE LIFT.

<u>DIMENSIONS</u>
CONTRACTOR/COUSTIMER TO VERIFY ALL DIMENSIONS AND REPORT DISCREPANCIES TO DUR OFFICE IMMEDIATELY. ₽NY

ELOBACJUPPORT WALL LDADS— STRUCTURAL ENGINEER TO ASSURE THAT BUILDING AND SHAFT WILL SAFELY SUPPORT ALL LDADS IMPOSED BY THE LIFT EQUIPMENT, REFER TO THE TABLES ON THIS DRAWING FOR LOADS IMPOSED BY THE EQUIPMENT.

<u>DOORS-</u> SUITABLE LINTELS MUST BE PROVIDED BY OWNER/AGENT DOOR FRAMES ARE NOT DESIGNED TO SUPPORT OVERHEAD WALL

LIGATIBN / ACCESS.— MACHINE RIDM LIGATED AT THE LIVEST LEVEL ADJACENT TO HOISTVAY, UNLESS SHOWN OTHERVISE IN THE LAYOUT DRAVINGS, FIELD ADJUSTMENT BY INSTALLER MAY BE NECESSARY TO MEET JOB SITE CONDITIONS OR RECOLLATIONS. ACCESS TO MACHINE RIDM TO BE THROUGH A SELF CLUSING AND SELF ACCESS

SLEEVES FOR OIL & ELECTRIC LINES- PROVIDED BY OTHERS, FROM MACHINE ROOM TO HOISTWAY. (POSITION PER INSTALLERS INSTRUCTIONS).

.IGHTS		? INFO	
115/1PH	230/1PH/60HTZ	208/3PH/60HTZ	INPUT VOLTAGE (V/PH/CYCLE)
	60	30	DISCONNECT SIZE (AMPS)
15	50	30	TIME DELAY   FULL LOAD   FUSE (AMPS)   CURRENT (#
	21	15.6	DISCONNECT   TIME DELAY   FULL LOAD SIZE (AMPS)   FUSE (AMPS)   CURRENT (AMPS)
		230/1PH/60HTZ 60 215/1PH	208/3PH/60HTZ 30 30 230/1PH/60HTZ 60 50 15/1PH 15

POWER SUPPLY— (SEE SPECIFICATIONS) LOCKABLE FUSED DISCONNECT WITH AUXILLARY CONTACT TO BRAKE THE BATTERY FEED, OR CIRCUIT BREAKERS VITH A 3-POLE BREAKER FOR BATTERY FEED REQUIRED, IN COMPLIANCE WITH ELECTRICAL CODE, AS FOLLOWS (LOCATED ON WALL ON LOCK JAMB SIDE OF MACHINE ROOM DOOR)

<u>LIGHTING-</u> DYNER/AGENT TO ENSURE AT LEAST 5 FTC OR 54 LUX AMBIENT LIGHTING OVER ELEVATOR AREA.

FASCIA PANEL BELDY UPPER LEYEL ENTRANCE: WHERE REGUIRED, FASCIA PANEL MUST BE FASTENED TO A SOLID WALL AND BE PERPENDICULAR TO THE FLOOR AND VALLS. HOISTVAY FASCIA IS NOT SELF-SUPPIRTING FOR LING, CONTINUOUS RUNS VOID OF ENTRANCES, ADEQUATE SUPPORT AND THE FASCIA MUST BE PROVIDED BY OTHERS.

RETURN VALLS. RETURN VALLS AT ENTRANCES MUST BE BUILT-IN BY OTHERS AFTER ENTRANCE ASSEMBLIES ARE IN PLACE. ENTRANCE ASSEMBLY MUST BE SECURELY FASTENED TO VALLS BY ELEVATOR CONTRACTOR. ENTRANCE ASSEMBLIES— ENTRANCE ASSEMBLIES MUST BE ADJUSTED TO ALIGN WITH PLATFORM AND INTERLOCK EQUIPMENT. OTHERS TO ALLOV AN ADEQUATE ROUGH OPENING.

MODEL LU/LA4854W